## **Cleaning and Care Instructions**



## for EasyClean-Pan® Products

#### **General information**

All EasyClean-Pan® products with GRP surfaces are suitable for regular wet cleaning, including high-pressure cleaners. The cleaning effect is influenced by 4 factors: temperature, cleaning agent, mechanics (water pressure), and time.

# WATER TEMPERATURE WATER PRESSURE MAX. MAX.

Limits

MAX. 50 °C

(with a nozzle distance of at least 30 cm)

120 bar

Exceeding the specified parameters may result in damage!

### **Application tips**

Note that if the water pressure is too high, dirt can be redistributed in the room via the resulting water mist. In addition, there are components such as connection joints at the floor/wall area that are often made with elastic sealants, which are not designed for such loads. Cleaning agents must always be rinsed off with clear water, otherwise discoloration may occur.



#### Do not use abrasive cleaners or solvents such as acetone!

Due to the wide variety of cleaning agents and cleaning requirements, we cannot provide a general approval for specific types of cleaning agents. As a rule, the mixing ratio specified by the cleaning agent manufacturer must be followed, regularly checked, and documented. Incorrect dosing can damage the GRP surface. The processing instructions of the cleaning agent manufacturers must be observed. Finally, the surfaces must be rinsed thoroughly with clear water; otherwise, discoloration of the surface may occur.

#### We recommend testing new cleaning agents on a small area in advance.

It is possible to request a compatibility test. For this, a sample of the cleaning agent (approx. 1 liter), the technical data sheet, and the relevant safety data sheets are required.

#### Disclaimer

The above notes and information are provided to the best of our knowledge and belief. The above notes do not constitute a guarantee for specific procedures or product properties.

